


# VACUUM INTERFACE UNITS

**6545872 VACUUM INTERFACE UNIT 5L, CONNECTION UPWARDS**

**Materials**

Tank: Stainless steel EN 1.4404  
 Float valve: rubber  
 Discharge valve: Polyacetal  
 Activator: Rigid PVC and polyacetal  
 Ventilator: Acetal/PVC  
 Mini-check valve: Acetal  
 Flexible tubing: EPDM hose  $\varnothing 14 \times 7\text{mm}$   
 EvacNoback valve body: PP

**Operating data**

Operating vacuum: -30... - 60 kPa  
 Minimum operating vacuum: -25 kPa  
 Normal activating head: 75mm  
 Activating volume: 5.4 L

**Capacity:**

-50 kPa: 2.2 L/s  
 -30 kPa: 1.2 L/s

**Connections:**


Outlet / vacuum line: Rubber sleeve connections to pipe DN40 and DN50 (EvacNoback valve)  
 Inlet / gravity line: Rubber sleeve connection to pipe DN40

**Shipping data:**

Net weight: 7kg  
 Shipping weight: 8kg  
 shipping volume: 0.08m<sup>3</sup>

# VACUUM INTERFACE VALVE

6545873 VACUUM INTERFACE UNIT 5L, CONNECTION DOWNWARDS



**Materials**

- Tank: Stainless steel EN 1.4404
- Float valve: Rubber
- Discharge valve: Polyacetal
- Activator: Rigid PVC and polyacetal
- Ventilator: Acetal
- Mini-check valve: Acetal
- Flexible tubing: EPDM hose Ø14 x 7mm

**Operating data**

- Operating vacuum: -30... - 60 kPa
- Minimum operating vacuum: -25 kPa
- Normal activating head: 75mm
- Activating volume: 5.4 L

**Capacity:**

- 50 kPa: 2.2 L/s
- 30 kPa: 1.2 L/s

**Connections:**

- Outlet / vacuum line: Rubber sleeve connection to pipe DN40
- Inlet / gravity line: Rubber sleeve connection to pipe DN40

**Shipping data:**

- Net weight: 6kg
- Shipping weight: 7kg
- shipping volume: 0.08m<sup>3</sup>


# VACUUM INTERFACE VALVES

6545872 VACUUM INTERFACE UNIT 5L, CONNECTION UPWARDS


6545873 VACUUM INTERFACE UNIT 5L, CONNECTION DOWNWARDS

## Installation examples

### Connection upwards



### Connection downwards / sidwards



### Pipe sizes

Gravity connection	Water trap unventilated	Water trap with automatic air valve
Maximum length A	3m	5m
Maximum size of vertical piping	OD 32mm	OD 32mm
Minimum size of horizontal piping	OD 50mm	OD 50mm

**! NOTE:** The maximum flow to the vacuum interface unit from all appliances must not exceed:


- 2.0 litres/second (not tested) at -50 kPa (3.0 m lift)
- 1.2 litres/second (not tested) at -30 kPa (3.0 m lift)

# VACUUM INTERFACE VALVES

6545872 VACUUM INTERFACE UNIT 5L, CONNECTION UPWARDS

6545873 VACUUM INTERFACE UNIT 5L, CONNECTION DOWNWARDS

## Connection upwards, details for bathroom




**! NOTE:** The maximum flow to the vacuum interface unit from all appliances must not exceed:


- 2.0 litres/second (not tested) at -50 kPa (3.0 m lift)
- 1.2 litres/second (not tested) at -30 kPa (3.0 m lift)

## Connection upwards, wash basin installation

### Installation on wall



### Installation on wash basin cabin



# VACUUM INTERFACE VALVE


6543521 VACUUM INTERFACE UNIT 2L, CONNECTION UPWARDS

6543469 VACUUM INTERFACE UNIT 2L, CONNECTION DOWNWARDS / SIDEWARDS

6545872 VACUUM INTERFACE UNIT 5L, CONNECTION UPWARDS


6545873 VACUUM INTERFACE UNIT 5L, CONNECTION DOWNWARDS

Vacuum interface unit 2L



- |  |  |
|--|--|
| 1. Vacuum hose                               | 8. Suction pipe (inside tank)            |
| 2. Activato                                  | 9. Adapter nuts                          |
| 3. Discharge valve                           | 10. Hose clamp                           |
| 4. Adapter                                   | 11. Ventilator valve                     |
| 5. Tank                                      | 12. Float (inside)                       |
| 6. Mini-check valve                          | 13. Sealing surface (inside float valve) |
| 7. Rubber diaphragm (inside discharge valve) |  |

Vacuum interface unit 5L



- |                      |
|----------------------|
| 14. Vacuum hose      |
| 15. Vacuum hose      |
| 16. Vent pipe        |
| 17. Nozzles          |
| 18. EvacNoback valve |

Trouble	Cause	Remedy
Vacuum interface unit does not operate. (Water rises in the bath or water basin.)	• If vacuum is less than -25kPa, vacuum is insufficient.	• Check vacuum collecting unit functioning.
	• Piping between bath/water basin and vacuum interface unit is blocked.	• Remove blockages.
	• Piping between vacuum interface unit and vacuum collecting unit is blocked.	• Remove blockages.
	• Activator does not operate.	• Check activator is operation: Remove vacuum hose(1) from the activator(2) and connect it directly to discharge valve(3). If valve opens, activator is not functioning. Replace activator.

# VACUUM INTERFACE VALVE

6543521 VACUUM INTERFACE UNIT 2L, CONNECTION UPWARDS

6543469 VACUUM INTERFACE UNIT 2L, CONNECTION DOWNWARDS / SIDEWARDS


6545872 VACUUM INTERFACE UNIT 5L, CONNECTION UPWARDS

6545873 VACUUM INTERFACE UNIT 5L, CONNECTION DOWNWARDS

Trouble	Cause	Remedy
Vacuum interface unit does not operate. (Water rises in the bath or water basin.)	• Activator does not operate.	<ul style="list-style-type: none"> <li>• Check that mini-check valve (6) or vacuum hose are not blocked. Remove blockages from the hose. If mini-check valve is blocked, replace/clean it.</li> <li>• Check that nozzles (17) are not blocked, clean as needed.</li> </ul>
	• Discharge valve or suction pipe is blocked	• Loose discharge valve and check whether rubber diaphragm (7) or suction pipe (8) is blocked. Remove blockages.
Vacuum interface unit leaks. (water overflow)	• Nuts and hose clamps are not tight. Float valve does not seal.	• Check adapter nuts (9) and hose clamps (10) tightness. Loose ventilator valve and check that float valve (12) and sealing surface (13) are clean. Clean if needed.
Discharge valve leaks. (vacuum leakage)	• Discharge valve does not seal.	• Disconnect vacuum hoses (14) from discharge valve to see if valve seals. If valve remains open even when vacuum hoses are disconnected, loose discharge valve and check whether rubber diaphragm is blocked.
Water traps are emptied each time when discharge valve operates.	• Ventilator valve does not operate.	• Check that ventilator valve opens each time discharge valve operates. Check that vacuum hose (15) is connected to the ventilator valve. Check that ventilator pipe (16) is open.
Discharge valve stays open.	• Activator does not operate.	• Replace activator.
	• Discharge valve is "blocked"	• Remove blockages.


# VACUUM INTERFACE VALVE

6545872 VACUUM INTERFACE UNIT 5L, CONNECTION UPWARDS



# VACUUM INTERFACE VALVE

6545873 VACUUM INTERFACE UNIT 5L, CONNECTION DOWNWARDS



# VACUUM INTERFACE VALVE


6543003 DISCHARGE VALVE

6545363 DISCHARGE VALVE

**6547327 RECOMMENDED SPARE PART KIT:**

1 x 6543004 Rubber diaphragm

2 x 6542990 Rubber sleeve



# VACUUM INTERFACE VALVE

6540524 VENTILATOR

P/N 5575000 and P/N 5575001 are replaced by P/N 6540524

